



# **SmartZone™ Network-Enabled MSPO Series Rack PDU**

## **User Manual**

**Release 1.0  
Issue 1.0**

Copyright © 2016 Panduit Corp. All rights reserved. No part of this book shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording or otherwise, without written permission from Panduit. No patent liability is assumed with respect to the use of the information contained herein.

Although every precaution has been taken in the preparation of this book, Panduit assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

## Table of Contents

<b>SmartZone™ Network-Enabled MSPO Series Rack PDU</b> .....	<b>6</b>
Contacting Panduit .....	6
Symbols Used .....	6
<b>Equipment Overview</b> .....	<b>8</b>
Voltage and Current Values .....	8
Model Numbering Format .....	8
Model Numbers .....	9
Additional Model Numbers and Numbering Format .....	10
<b>Pre-Installation</b> .....	<b>12</b>
Product Inspection .....	12
<b>Installation</b> .....	<b>13</b>
Before You Begin .....	13
Standard Accessories .....	13
Mounting Hardware: .....	13
Cables/Adapters: .....	13
Hardwire PDU installation instructions .....	13
Unterminated Cord PDU installation instructions .....	15
Optional Accessories .....	16
SmartZone Environmental Sensors: .....	16
Additional Required Items .....	16
Safety Precautions .....	16
Servicing .....	16
Product Safety Warnings .....	16
Rules .....	17
Environmental Specifications .....	18
Bonding .....	18
<b>Mounting</b> .....	<b>19</b>
Vertical Mounting .....	19
PDU Bracket for 4-Post Racks .....	21
PDU Bracket for 2-Post Racks .....	22
Horizontal Mounting .....	23
<b>Hardware</b> .....	<b>24</b>
LCD Display .....	24
Reset Button .....	24
Mode Button Operation .....	25
Bootloader Startup .....	25
Firmware Recovery Mode .....	25
Application Startup .....	25
Internal Error Notification .....	26

<b>Graphical User Interface</b> .....	<b>27</b>
Access the PDU Graphical User Interface .....	27
<b>Setup</b> .....	<b>30</b>
IP Config .....	30
IPv4 Address Configuration .....	31
The DHCP configuration (Dynamic Addressing provided by Infrastructure) ....	32
Static Configuration (Manual Addressing) .....	32
IPv6 Address Configuration .....	32
AutoConfig only (link local addressing) .....	32
Static configuration (manual addressing) .....	32
DHCPv6 configuration (dynamic addressing provided by infrastructure) .....	33
Accessing the appliance via a web browser using IPv6 .....	33
HTTP .....	33
SNMP NMS .....	34
SNMP Receivers .....	36
SNMP Trap Description Text Format .....	37
Users .....	38
Email Alerts .....	40
Time Settings .....	41
Time Adjustments .....	41
Syslog Servers .....	42
Events .....	43
Preferences .....	43
Restart .....	45
<b>Input Sensors</b> .....	<b>46</b>
Status .....	46
Defaults .....	47
Configure .....	52
Sensor Trap Text .....	53
<b>Power</b> .....	<b>55</b>
Status Single-Phase .....	55
Status 3-Phase .....	55
Branch Monitoring .....	56
Thresholds .....	57
Configure .....	57
RMS Volts .....	60
RMS Current .....	61
Total Energy .....	62
Apparent Power .....	63
True Power .....	64
Power Factor .....	65
Power Strip Outlets .....	66
Cfg Aggregate .....	67

---

Monitor Trap Text .....	68
Outlet Trap Text .....	69
Control .....	69
Config Outlet Groups .....	71
Outlet Group Control .....	73

# SmartZone™ Network-Enabled MSPO Series Rack PDU

Network-Enabled MSPO (Monitored and Switched Per Outlet) Series Rack PDUs integrate with the Panduit PIM Software Platform and other SmartZone applications to enable intelligent management of in-cabinet power usage. This system helps to quickly identify potential power overload issues in order to aid in resolution, identify underutilized power capacity for efficient deployment of network resources, and automate collection of real-time power information.



The MSPO Series PDU monitors per-phase power, voltage and current, per-outlet power, voltage and current, per-branch current, and includes the ability to switch the power to each outlet off or on.

SmartZone™ Network-Enabled PDUs are available in a wide range of configurations and power connections and outlets and can be mounted vertically or horizontally.

## Contacting Panduit

For Technical Support on PDU hardware and associated software, please contact Panduit Technical Support using one of the following methods:

1-866-721-5302 (toll-free)  
Monday-Friday, 7:30 am - 5:00 pm CST  
systemsupport@panduit.com

## Symbols Used

Symbol	Description
	Danger – Electric Shock Hazard
	Warning – Possible Safety Hazard
	Primary Earth Ground

Symbol	Description
	Secondary Earth Ground
	ON
O	OFF

## Equipment Overview

The power inlet/cord(s) connects the PDU to the electrical power source. On metered PDUs, the LCD displays the current load for each input feed or electrical phase per input feed.

- One shielded RJ45 connector for Ethernet connection
- Two unshielded RJ45 connectors for SmartZone™ sensors (For a list of supported sensors, see "Optional Accessories".)

For IEC C-20 inlet PDUs, a customer-supplied cord is used for connection to the power source. The connection end to the PDU has an IEC C-19 plug for connection to the PDU. The opposite end of the cord shall have a plug suitable for connecting to the customer supplied receptacle. The cord and plug shall be rated for 20A in North America and 16A outside of North America. The connection to the PDU should be made prior to connecting to the power source.

## Voltage and Current Values

Non-U.S./Canada		U.S./Canada	
Voltage	Current	Voltage	Current
240, 415	10, 13, 16, 20, 30, 32, 48, 63	120, 208	12, 16, 24, 40, 48

## Model Numbering Format

This section describes the model numbering format used to identify equipment in the PDU series. PDU devices are numbering using one of the following formats:

- **P1N-ABCDEFGHIJKLM**
- **Q1N-ABCDEFGHIJKLM**

The P1N prefix indicates that the model is intended for horizontal mounting. The Q1N prefix indicates that the model is intended for vertical mounting. The remaining series of letters represent values as defined in the table below.

Letter	What It Represents
<b>A</b>	any numeral, 1-8, indicating the phase wiring for the output circuit breakers and receptacles
<b>B</b>	Any letter, A-F, indicating input cord configuration
<b>CD*</b>	Any numeral, 1-5, and any letter, A-Z, indicating input plug type and rated voltage
<b>E</b>	Any numeral, 1-7, indicating the number of output circuit breakers
<b>F</b>	Any letter, A-Z, indicating the type of overload protection provided for the outlets
<b>GH</b>	Any two numerals, 01-45, indicating the number of output receptacles provided
<b>JK</b>	The letter 'A' or 'B' followed by any letter, A-Z, indicating the type and quantity of output receptacles provided
<b>L</b>	Any numeral, 0-9, or any letter, A-Z, indicating the length of the power supply cord
<b>M</b>	Any numeral, 0-9, indicating the color of the enclosure

\* Voltage and amperage ratings:

120V, single-phase, 10A, 12A, 15A, 16A, 20A, 24A or 30A

208V, single-phase, 10A, 12A, 13A, 15A, 16A, 20A, 24A, 30A, 48A or 60A

230V, single-phase, 16A, 32A, or 48A

208V, three-phase (delta), 16A, 20A, 24A, 30A, 40A, 48A, 50A or 60A, 3W + PE

208V, three-phase (wye), 16A, 20A, 24A, 30A, 48A or 60A, 3W + N + PE

400V, three-phase (wye), 16A, 20A, 24A, 30A, 32A, 48A or 60A, 3W + N + PE

## Model Numbers

Part Number
P1N1B1C0A10AKA0
P1N1B1L2N08ATA0
P1N1B1M2M10AKA0
Q1N1A3W0A24AF00
Q1N1B1C0A24AKA0
Q1N1B1D0A24AKA0
Q1N1B1E0A30AHA0
Q1N1B1F0A30AHA0

Part Number
Q1N1B3H0A24AFA0
Q1N1B3H0A30AHA0
Q1N1B3H0A30AXA0
Q1N2B1J0A30AHA0
Q1N2B1L2N30AHA0
Q1N2B1M2M24AKA0
Q1N2B1N3N30AHA0
Q1N2B1P3N30AHA0
Q1N2B2C3N30AHA0
Q1N2B2P6M30AHA0
Q1N2B2Q0A30AHA0
Q1N2B2T6N30AHA0
Q1N2B2W6N30AHA0
Q1N2B2W6N30APA0
Q1N2B3J2M30AHA0
Q1N2B4E3N30AEA0

## Additional Model Numbers and Numbering Format

In addition to the listings above, the model numbers listed below are also covered, based on the naming conventions explained in the table that follows.

Part Number
HQ-208V30A
HQ-240V16A
HT-208V30A
VQ-240V16A
VT-208V60A
VT-415V32A
VW-208V60A
VW-415V32A

The format used for these model numbers is: **AB-xxxVyyA**

Letter	What It Represents
<b>A</b>	H = Horizontal V = Vertical
<b>B</b>	Q = Monitored with Monitored Per Outlet (Network Connection) T = Monitored with Monitored & Switched Per Outlet (Network connection) W = Monitored with Switched Per Outlet (Network Connection)
<b>xxxV</b>	Any voltage from 100 - 415
<b>yyA</b>	Amps, from 10 - 80

## Pre-Installation

The Rack PDU products covered by this guide are designed to be installed within EIA racks and cabinets. Use of this product in other applications is acceptable, but other precautions may be required to allow for specific installations not covered by this guideline.

## Product Inspection

Inspect the product prior to installation. If the product has any visible signs of damage, please contact the supplier.

# Installation

## Before You Begin

Before installing your PDU, refer to the following lists to ensure that you have all the items shipped with the unit as well as all other items required for proper installation.

## Standard Accessories

### Mounting Hardware:

- Vertical models:  
Affixed button mounts
- Horizontal models:  
Appropriate local mounting brackets and screws


### Cables/Adapters:

- RJ45 patch cord cable


## Hardwire PDU installation instructions

This product is intended to be hardwired by the customer must be installed by a qualified electrician AND adhere to all national & local electrical codes.

1. To install, remove the (4) securing screws on the removable user panel.
2. Unscrew strain relief grommet cap (indicated below) and feed the power cable through the grommet cap & the input gland.



3. Ensure conductors are stripped adequately, exposing 15mm of copper.
4. Conductors shall be connected in-line with the terminal markings provided as shown below (Line 1 = X; Line 2 = Y; Line 3 – Z). Ensure screws are secure for each conductor by applying a torque of 2.3 N-m (20 in-lb.).



5. Ensure conductors have enough slack (none should be under tension).
6. Feed grommet cap down cord and secure to input gland. Reference the table below to ensure the grommet cap is torqued correctly.

Gland Size	Grommet Cap Torque
M16	1.5 N-m (13 in-lb.)
M20	3.0 N-m (27 in-lb.)
M25	4.0 N-m (35 in-lb.)
M32	
M40	15 N-m (132 in-lb.)
M50	20 N-m (177 in-lb.)
M63	30 N-m (266 in-lb.)

7. Re-install removable cover plate with the screws removed in step 1.
8. Connect the other end of the power cord to a suitably rated disconnect device.
9. Switch utility circuit breaker “On”.

## Unterminated Cord PDU installation instructions

This product is intended to be hardwired by the customer must be installed by a qualified electrician AND adhere to all national & local electrical codes.

To install, match the corresponding conductor color to the matching phase in your facility. Reference the color guide below:

Conductor Insulation Color	Line Number / Phase
Brown	Line1 / X
Black	Line 2 / Y
Grey	Line 3 / Z
Blue	Neutral
Green (may include Yellow stripe)	Ground

## Optional Accessories

### SmartZone Environmental Sensors:

- Smoke Sensor
- Humidity Sensor
- Water Rope Sensor
- Door Sensor
- Temperature Sensor
- Water Contact Sensor
- Air Flow Sensor
- Passive Infra-Red Motion Detector

## Additional Required Items

- Flathead and Phillips screwdrivers
- Appropriate local AC power receptacle to power the PDU
- Local active Ethernet port to communicate with the PDU

## Safety Precautions

This section contains important safety and regulatory information that should be reviewed before installing and using the Rack PDU.

### Servicing

There are no user-serviceable parts inside these products. Any maintenance or repair must be performed by approved service-trained personnel. Opening the unit will void the product warranty.

### Product Safety Warnings



**Warning:** Use only in dry locations. Indoor use only.

PDU hardware has an International Protection Rating of IPX0.

The installer must connect the power distribution unit to an electrical supply that has a protective Earth conductor.

For pluggable equipment, the socket outlet should be installed near the equipment and should be easily accessible.



**Warning:** For permanently connected equipment, a readily accessible disconnect device should be incorporated external to the equipment.

Power distribution products must be protected by a branch circuit protective device rated at the maximum rating of the product specified on the product rating label.

To avoid risk of overload, do not plug additional multiple outlet power distribution devices into the power distribution unit socket outlets.

This equipment is intended only for installation and use in a Service Access Location in accordance with the following installation and use instructions.

This equipment is designed to be installed on a dedicated circuit.

- The dedicated circuit must have circuit-breaker or fuse protection.
- Rack PDUs have been designed without a master circuit breaker or fuse to avoid becoming a single point of failure. It is the customer's responsibility to provide adequate protection for the dedicated power circuit. Protection of capacity equal to the current rating of the Rack PDU must be provided and must meet all applicable codes and regulations. In North America, protection must have a 10,000A interrupt capacity.



**Warning:** Always disconnect the power supply cord before opening to avoid electrical shock.



**Danger**  
Electric shock risk

**DANGER:** High leakage current! Earth connection is essential before connecting supply!



**Danger**  
Electric shock risk

**DANGER:** Double Pole/Neutral Fusing: The plug on the power supply cord must be installed near the equipment and must be easily accessible.

## Rules

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in

accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes/modifications not approved by the responsible party could void the user's authority to operate the equipment.

## Environmental Specifications

- Operating Temperature: 0C to 40C
- Transportation Temperature: -10C to 70C
- Operating Humidity: 15% to 85% non-condensing
- Transportation Humidity: 5% to 90% non-condensing

## Bonding

This product contains an external earthing screw with a star washer, which should be used for supplementary Earth bonding to the rack metalwork.

<b>Bonding</b>	
<b>Minimum Requirements for Bonding Conductors</b>	
Up to and including 32A	12 AWG
Up to and including 63A	8 AWG
Up to and including 80A	6 AWG
<b>Screw Size</b>	
Over 16A, less than or equal to 40A	5mm
Over 40A, less than or equal to 63A	6mm
64A	7mm

# Mounting


There are two mounting options for Rack RDUs


- Vertical Mounting
- Horizontal Mounting

Instructions for each mounting option are detailed below.


## Vertical Mounting

The product is intended to be installed using the tool-less mounting buttons. These buttons locate in the fixing holes provided as shown in the following figure.





### PDU Bracket for 4-Post Racks




CVPDUB- Pair of Brackets for Vertical PDU Button Mounting to the side of the rack post.

The diagram shows two CVPDUB brackets, each with a 3x3 grid of circular ports. One bracket is shown being secured to a vertical rack post with a screw. The label "#12-24 Screws" points to the screw being used for mounting. The label "CVPDUB" is placed below the two brackets.

Align bracket to desired location on rack post, then secure with #12-24 screws.

## PDU Bracket for 2-Post Racks



**R2PPDUB**

The R2PPDUB part contains the following components referred to in this instruction sheet:

- (2) Outer Mounting Brackets
- (2) Inner Mounting Brackets
- (12) #12-24 X 1/2" Screws


### Installation Instructions-Outer Mounting Brackets

Attach (2) #12-24 X 1/2" screws to rack (per bracket) at appropriate locations.

Fasten outer mounting brackets to rack using the screws. The large flat surface with slotted holes may face outside or inside.

For mounting long (66.25") POU's, the brackets may be spaced vertically between 35 and 39 RU apart, in 1 RU increments, measured from bracket base to bracket base.

For mounting short (39") POU's, the brackets may be spaced vertically between 19 and 23 RU apart, in 1 RU increments, measured from bracket base to bracket base.



### Installation Instructions-Inner Mounting Brackets

Slide inner mounting brackets into outer mounting brackets with the POU mounting keyway surface facing opposite the outer bracket slotted hole surface. Fasten brackets together using (4) #12-24 X 1/2" screws for each bracket set. (2) screws will be fastened on the top flange and (2) screws will be fastened on the bottom flange.

**Important:** (2) screws must be fastened in the most **outward** hole on each **outer** mounting bracket (1 top, 1 bottom). (2) screws must be fastened in the position where the hole in the **inner** mounting bracket is **closest** to the face of the rack, regardless of extended position.


**Note:** Multiple holes on the top and bottom of the brackets allow the distance from the rack a POU can be mounted to be adjustable. This means that the side facing POU can be mounted ranging from 3.7"-18.7" horizontally from the face of the rack. The rear facing POU can be mounted ranging from 12.3"-20.3" horizontally from the face of the rack.

## Horizontal Mounting

This product is intended to be installed using the rack's RU mountings via the brackets found at either end of the PDU with the accessory screws provided listed below.

- Horizontal Models  
North American units  
(4) #10-32 x 1/2" MOUNTING SCREWS  
(4) #12-24 x 1/2" MOUNTING SCREWS

- Global units  
(4) M6 x 20mm MOUNTING SCREWS  
(4) #12-24 x 1/2" MOUNTING SCREWS



# Hardware

## LCD Display

The display shows the firmware version number, device model number, serial number, MAC Address, IP Address, and electrical readings. The display automatically scrolls through the readings. Readings that can be displayed include:

- Start Up messages
- Configuration/serial/product number messages
- Error/Status messages
- Aggregate data
- Single phase data, 3 Phase Delta data, or 3 Phase Wye data
- Branch current data, if the unit has breakers

During normal operation, the mode button may be used to quickly advance through the LCD display pages.

## Reset Button

Push the **Reset** button using a non-metallic item, similar in size to a paper clip, to reset the PDU device.



**Warning:** a metallic item, such as a paper clip, is not recommended as a reset tool.

The reset tool should be inserted perpendicular to the surface of the device and pressed until the button is reached and is actuated.

The reset tool should bump into the button within 1/8 of an inch of being inserted, and should be lightly depressed and held for at least 1 second. The reset tool should never be inserted more than 1/4 of an inch.

Resetting the PDU device starts the bootloader.

*For PDUs with bootloader versions 2.3.03 and 2.3.04:* Wait between 1 and 30 seconds for the Display Backlight to blink on and off at a rate of 2 blinks per second. The bootloader stays in this mode for at least 4 seconds (8 blinks) if no user operation is detected.

*For PDUs with bootloader versions 2.3.05:* Wait between 1 and 30 seconds for the Display Backlight to blink on and off at a rate of 4 blinks per second. The bootloader stays in this mode for at least 2 seconds (8 blinks) if no user operation is detected.

## Mode Button Operation

### Bootloader Startup

When the user presses and holds the **Mode** button, the Display Backlight switches to one blink per second, indicating the bootloader is waiting for one of the following operations.

- If the user releases the **Mode** button after two blinks, the backlight goes solid-on and stays in the bootloader, entering the “firmware recovery mode”. See the “Firmware Recovery Mode” section (below) for more details.
- If the user releases the **Mode** button after four blinks, the backlight goes solid-on and attempts to boot the “backup firmware image”.
- If the user does not operate the **Mode** button as described above, the Display Backlight is turned off. The “firmware updatable application image” continues loading.

### Firmware Recovery Mode

The Network-Enabled PDU provides a firmware recovery mode in case a firmware update is interrupted while in progress and fails to complete successfully.

**Note:** Do not power cycle or restart a device while a firmware update is in progress.

If a firmware update does not complete successfully, and the device fails to be operational after 30 minutes, contact Panduit Technical Support.

1-866-721-5302 (toll-free)

Monday-Friday, 7:30 am - 5:00 pm CST

[systemsupport@panduit.com](mailto:systemsupport@panduit.com)

### Application Startup

When the application is ready, a message is displayed on the LCD:

```
Starting up...
```

The display backlight blinks quickly three times and remains lit.

The LCD then displays:

Hold MODE button to reset to defaults...

The application stays in this mode for at least 5 seconds. If no button operation is detected, the application continues to normal system operation.

If the customer presses and holds the **Mode** button for 5 seconds, the following message displays on the LCD:

```
Hold MODE button more than 5 seconds to reset to defaults
```

If the customer continues to press and hold the **Mode** button, the following message displays on the LCD:

```
Reset to defaults is detected. Please release MODE button.
```

The customer should release the **Mode** button at this point. The following message displays on the LCD:

```
Device is Resetting to factory defaults.
```

If the customer does not operate the **Mode** button as described above, the application continues normal system operation.

### Internal Error Notification

After system start up is complete, during normal operation of the unit, the LCD screen may blink. This typically indicates a temporary or persistent internal error condition.

If the condition is persistent, the LCD screen displays the word "STATUS:" followed by a hexadecimal code, similar to the following.

```
STATUS: 0x009000080
```

The hexadecimal code is a composition of per-outlet control, per-outlet monitoring and per-phase monitoring status. For example, if a three phase Per-outlet Monitoring or Switched unit loses a power phase, the status screen will reflect that communication to those boards has been lost.

For definitions and recommended actions on status codes, provide the displayed hexadecimal number to Panduit Technical Support.

## Graphical User Interface

The Panduit Network Enabled Rack PDU provides access to configuration, power, and sensor data through a Graphical User Interface (GUI), using a standard browser. There are several ways to connect to the device's GUI, depending on your network configuration and the firmware revision of the device.

If the PDU has firmware revision 2.3.03 (or earlier), Static IP is the default. The configuration settings in this case are:

IPv4 Address:192.168.0.253

IPv4 Network:255.255.255.0

IPv4 Gateway:192.168.0.1

If the device has firmware revision 2.3.04 (or later), DHCP is the default, and one of the following scenarios will be used.


- If you have a DHCP Server available, connect to the appliance through that server, using the PDU's IP Address.

**Note:** The IP address for the Rack PDU is displayed on the device's LCD screen after the label IPv4

- If you do not have a DHCP server, you can run one on your PC. To connect to the device, use the IP address displayed on the LCD screen.
- If you want to use automatic IPv4 address configuration, you must activate DHCP on your PC and then connect directly to the PDU. This will give you an address on the 169.254.0.0/16 network. You can then connect directly using the IP Address displayed on the LCD screen.

## Access the PDU Graphical User Interface

To access the GUI, open a web browser and enter the IP Address of the PDU. When the login page opens, you will be prompted to enter a Login and Password.




The default login and password are:

Login:admin

Password:admin


After successful login, the GUI opens to the Overview page.



There are three modules within the GUI, each providing access to a different area within the PDU. The modules are:

- Set Up
- Input Sensors
- Power

To select a module, click the appropriate label along the top of the display.



The menu items that appear on the left hand side of the screen will change depending on the module selected.

## Setup


When the setup module is selected, the following menu items appear along the left hand side of the display.

Setup Menu Options	
IP Config	View or edit the network settings
HTTP	View or edit the HTTP settings
SNMP NMS	View or edit information about NMS access
SNMP Rec'rs	View or edit information about the SNMP Receivers
Users	View or edit information about all users
Email Alerts	View or edit email alert settings
Time Settings	View or edit information about the date and time
Syslog Servers	View or edit information about the Syslog servers
Events	View Event history
Preferences	View or edit system preferences
Restart	Provides the ability to restart the PDU

Detailed information on each of these menu items can be found in the corresponding sections below.

### IP Config

Selecting this option displays the IP Configuration page, where network settings for the unit can be set. This is the information that will be displayed on the Overview page.



IP Configuration	
System Name	The name of the PDU
System Location	The location of the PDU
Contact Name	A person to contact regarding the PDU
Config Protocol	Select the configuration protocol
IP Address	The IP address of the PDU
Subnet Mask	The Subnet Mask for the PDU IP Address
Gateway	The Gateway for the PDU IP Address

### IPv4 Address Configuration

There are several kinds of IPv4 address configurations that you can choose from. Static IPv4 is the default configuration for firmware releases before firmware version 2.3.04. DHCP is the default configuration for firmware releases after firmware releases 2.3.03.

### The DHCP configuration (Dynamic Addressing provided by Infrastructure)

- The DHCPv4 client allows the user to obtain IPv4 configuration information from a DHCPv4 server. The functions that the DHCPv4 client performs include:
  - Basic server discovery and address assignment.
  - Address renewal and rebinding.
  - Address deprecation when the preferred lifetime expires.
  - Address removal when the valid lifetime expires.
  - Address release when the interface is closed.

### Static Configuration (Manual Addressing)

- The customer must specify an IP address, Subnet mask, and Gateway.

### IPv6 Address Configuration

There are several kinds of IPv6 address configuration that can be chosen.

#### AutoConfig only (link local addressing)

- IPv6 AutoConfig addressing is always available.
- The customer does not specify an IP Address, IPv6 prefix (shown as Subnet Mask in the web UI) or Gateway.
- The link local address is always based on the MAC Address converted into an EUI-64 address.

For example, the MAC Address: 00:07:6E:04:01:28 is always accessible at the IPv6 Link local address: FE80::0207:6EFF:FE04:0128.

Note that the first byte of the MAC address has 0x02 added to it where FF:FE is inserted into the middle of the MAC address bytes. The technical term for this address format is stateless address autoconfiguration (SLAAC) using the modified EUI-64 format.

#### Static configuration (manual addressing)

- The customer must specify an IP Address, IPv6 prefix (shown as Subnet Mask in the web UI) and Gateway.
- Static IPv6 configuration works concurrently with stateless address auto-configuration.

### DHCPv6 configuration (dynamic addressing provided by infrastructure)

The DHCPv6 client allows the user to obtain IPv6 configuration information from a DHCPv6 server and works concurrently with stateless address autoconfiguration. The functions performed by the DHCPv6 client include:

- Basic server discovery and address assignment
- Address renewal and rebinding
- Address deprecation when the preferred lifetime expires
- Address removal when the valid lifetime expires
- Address release when the interface is closed

The current implementation of the DHCPv6 client has certain limitations. The following are the features that are currently not supported:

- Authentication
- RECONFIGURE Messages
- IA\_TAs (Temporary Addresses)
- Rapid Commit FQDN (Fully Qualified Domain Name)
- DUID-LLT
- IA\_PD (Identify Association for Prefix Delegation)

### Accessing the appliance via a web browser using IPv6


A web browser can access IPv6 addressed devices using the full or short form IPv6 address.

For example, to access an appliance with the MAC address 00:07:6E:04:01:28, you could navigate to the AutoConfig address: [http://\[FE80::0207:6EFF:FE04:0128\]/](http://[FE80::0207:6EFF:FE04:0128]/) or [https://\[FE80::0207:6EFF:FE04:0128\]/](https://[FE80::0207:6EFF:FE04:0128]/) . The open and close square brackets indicate an IPv6 address.

When using a PC with more than one IPv6 enabled network interface (multi-homing), IPv6 scoped URLs may be necessary to access a device. Not all web browsers fully support IPv6 scoped URLs. Therefore, this problem must be worked around by enabling IPv6 on only one interface at a time on the computer running a web browser to access the appliance.

## HTTP

This page allows you to choose the access method for the web management interface.



To choose the access method, click the corresponding radio button and enter the appropriate **Port** number. Typically the Port does not need to be changed from its default setting (80 for HTTP or 443 for HTTPS).

HTTP or HTTPS access methods can be used. However, HTTPS is recommended for security.

When you save any changes to this page, you will see the following message:


```
After Saving, would you like to restart the unit?
```

```
Click 'OK' to restart, otherwise 'Cancel'.
```

If you select **Cancel**, you are reminded that you will need to manually restart for any changes to take effect.

## SNMP NMS

This page provides access for Network Management Stations.



Both SNMPv2c and SNMPv3 protocols are supported simultaneously. You must enter the credential information for any device that needs to communicate with the unit via Simple Network Management Protocol (SNMP).

Select the SNMP version settings you wish to edit from the drop-down menu.

For ease of initial deployment and discovery, default credentials for both versions have been provided:

- The SNMPv2 default Community Strings are “public” (read-only access) and “private” (read/write access).
- The unit will respond to SNMPv3 requests using the MD5 authentication and DES privacy protocols. To use the "authUser" and "secureUser" user names, an Authentication and/or Privacy password must first be set.
- To disable a specific version of SNMP, simply remove the Community Strings (SNMPv2c) or User Names (SNMPv3) and save the configuration.

Enter the **Community String** for any device that must access the unit’s SNMP functions.

Access permissions can be selected from the drop-down menu under **NMS Access**.

Access Permission Settings	
Read Only	Permits the NMS to use only GET commands
Read / Write	Permits the NMS to use both GET and SET commands

## SNMP Receivers

The **SNMP Receivers** page displays information for all devices that receive SNMP traps sent from this unit.

Logged In: admin ( Administrator )  
System Name: iPDU-04:01:19  
Logout

Setup / SNMP (Receivers)

Overview: SNMP Trap Receivers are configured here. Any machine which will be required to receive SNMP traps sent from this unit must be entered here.

IP Config: Notes: Authentication failure traps, when enabled, are generated if an attempt is made to access the unit with an invalid community string.

HTTP: v3 Traps are sent in a snmpv2-trap format contained within a SNMPv3 message. Authentication or Encryption is not supported.

SNMP NMS: All Traps are generated to port 162.

Users	Receiver IP Address:	Receive Traps:	Trap Version:
Email Alerts	Receiver 1	Disabled	v1
Time Settings	Receiver 2	Disabled	v1
Syslog Servers	Receiver 3	Disabled	v1
Events	Receiver 4	Disabled	v1
Preferences	Receiver 5	Disabled	v1
Restart	Receiver 6	Disabled	v1
	Receiver 7	Disabled	v1
	Receiver 8	Disabled	v1
	Receiver 9	Disabled	v1
	Receiver 10	Disabled	v1

Test All Save

Enter the **IP address** and **Community String** for any device that will be required to receive SNMP traps. Usually any SNMP NMS entries should also be entered here. From the dropdown menu under **Receive Traps**, select one of the following:

Receive Traps Settings	
Disabled	Receiving traps is prohibited
Enabled	Allows the specified NMS to receive the unit's standard

Receive Traps Settings	
	range of traps
Enabled (Incl. Auth Fails)	Receive traps – causes the unit to issue traps if there is an unauthorized attempt to access the unit's SNMP functions.

The version of trap/notification can be selected from the dropdown menu under **Trap Version**.

### SNMP Trap Description Text Format

SNMP Traps are detected when certain events are detected. The format of the generated text messages is explained below.

NOTE: Before the text message is sent, all leading, trailing and repeated whitespace is removed.

The SNMP trap text format is:

```
<snmp-trap-format> ::= <opt-timestamp-prefix> " " <opt-system-name> " " <opt-system-location> " " <opt-contact-name> " " <trap-kind> " " <source-name> " " <chan-no> " " <user-text> " " <value> " " <data-type> " " <opt-timestamp-postfix>
```


The following table contains definitions for each parameter.

SNMP Trap Text Format	
<opt-system-name> ::= <text>	Optional. When Setup -> IP Config / System Name / Include In Trap is checked, Setup -> IP Config -> System Name is displayed.
<opt-system-location> ::= <text>	Optional. When Setup -> IP Config / System Location / Include In Trap is checked, Setup -> IP Config -> System Location is displayed.
<opt-contact-name> ::= <text>	Optional. When Setup -> IP Config / Contact Name / Include In Trap is checked, Setup -> IP Config -> Contact Name is displayed.
<opt-timestamp-prefix> ::= <text>	Optional date/time prefix. (When Setup / Preferences Timestamp Traps: is set to "Prefix".)
<trap-kind> ::= <text>	Type of notification. Warning, Critical, Information

SNMP Trap Text Format	
	On, Information Off, Cleared, Unknown.
<source-name> ::= <text>	Data source. Example: "Input 01".
<chan-no> ::= "(" <number> ")"	When available, the number of the sensor Port the alert came from.
<user-text> ::= <text>	Event description of the reason for the trap. See the "User Text" strings on the Trap Configuration pages or the per-sensor configuration pages. Example: For contact sensors, the "Normal Trap User Text" or "Non-Normal Trap User Text" is used.
<value> ::= <text>	The value at which the event occurred. Example: "900" indicates 90% humidity.
<data-type> ::= <text>	Type of the data. Example: "relative humidity"
<opt-timestamp-postfix> ::= <text>	Optional date/time postfix. (When Setup / Preferences Timestamp Traps: is set to "Append".)

## Users

Select the **Users** menu item to add or modify Web GUI User settings.



The PDU GUI comes with the Administrator login predefined as:

- **Login:admin**
- **Password:admin**

To add new users, enter a unique **Username** and **Password** for each, then select the desired level of permission. You may configure up to 20 users.

Level of permission for each user can be selected from the drop-down menu on the right. There are three different permission settings:

User Permission Settings	
Administrator	Allows all configuration settings to be viewed and modified
Controller	Allows configuration settings to be viewed, but only certain pages can be modified
Viewer	Allows configuration settings to be viewed only

## Email Alerts

On this page, you can edit email alert settings for traps. You may set up to 10 email receivers.

Logged In: admin ( Administrator )  
System Name: iPDU-04:01:19  
Logout

Setup / Email Alerts

SMTP Relay Server: [Input Field]  
From Address: [Input Field]  
Reply-To Address: [Input Field]

Email Receivers

No.	Destination Address	Enabled	Repeat Timer
1	[Input Field]	<input type="checkbox"/>	0 mins.
2	[Input Field]	<input type="checkbox"/>	0 mins.
3	[Input Field]	<input type="checkbox"/>	0 mins.
4	[Input Field]	<input type="checkbox"/>	0 mins.
5	[Input Field]	<input type="checkbox"/>	0 mins.
6	[Input Field]	<input type="checkbox"/>	0 mins.
7	[Input Field]	<input type="checkbox"/>	0 mins.
8	[Input Field]	<input type="checkbox"/>	0 mins.
9	[Input Field]	<input type="checkbox"/>	0 mins.
10	[Input Field]	<input type="checkbox"/>	0 mins.

Test All Save

Email Alerts	
SMTP Relay Server	The IP Address of the SMTP Server
From Address	Address from which the alert emails are sent
Reply-To Address	Address to which the email receivers can reply
Destination Address	Address that will receive the email alerts
Enabled	Toggle the check box to enable or disable alerts to each address.
Repeat Timer	Number of minutes after which the email alert will repeat

## Time Settings

The **Time Settings** page allows you to view or edit the current date and time.

The screenshot displays the PANDUIT web interface for Time Settings. At the top right, it shows 'Logged In: admin ( Administrator )', 'System Name: iPDU-04:01:19', and a 'Logout' link. Below this are tabs for 'Setup', 'Input Sensors', and 'Power'. The 'Setup' tab is active, showing a sidebar with various configuration options. The main content area is titled 'Setup / Time Settings' and includes the following fields:

- Date:** 6 January 2006
- Local Time:** 17 : 47 : 43  Update time
- Time Adjustments:**
  - Timezone:** (GMT) Dublin, Lisbon, London
  - Daylight Saving:**  Enabled
    - Start the 4th Sunday in March
    - Stop the 4th Sunday in October
  - Date Format:** dd/mm/yyyy
- SNTP Servers:**
  - Primary Server:**   Enabled
  - Secondary Server:**   Enabled
  - NTP Update Freq.:** 1 Hours

A 'Save' button is located at the bottom right of the form.

Select the correct day, month, and year from the dropdown menus, and verify the local time. If you want to change the time, you must check the **Update time** checkbox.

### Time Adjustments

Select the correct time zone from the drop-down menu.

- **Daylight Saving** can be enabled or disabled by clicking the check box. If Daylight Saving is enabled, select start/stop dates from the subsequent drop-down menus.
- **Date Format** allows the administrator to choose whether the date is displayed with the day or month first. For example, the date August 20, 2013 can be displayed in one of two ways:

20/08/2013 (DD / MM / YYYY)

or


08/20/2013 (MM / DD / YYYY)

Select the desired format from the dropdown menu.

- **SNTP Servers - Simple Network Time Protocol** synchronizes the clocks of computer systems over a network. Enter the IP address of an SNTP server, and specify (in hours) how often the time should be updated.

## Syslog Servers

This page allows you to view or edit information about the Syslog Servers currently being used.



From the **Enabled** drop-down menu, you can choose which syslog servers are enabled. Fill in the following fields for each Syslog server.

Syslog Server Setup	
Display name	The name of the Syslog server
IP Address	The IP address of the Syslog server
Port	The number of the port being used
Log Event Types	Click the check boxes to choose which events to log.

## Events

The View Events page shows a history of events that have occurred, along with specific details about each event.

Logged In: admin ( Administrator )  
System Name: iPDU-04:01:19  
Logout

Setup Input Sensors Power

View / Events

Overview

IP Config View Events: 2000 January Latest First Earliest First [Show] [<Prev] [Next>]

	Date / Time	Type	User	Event Data
SNMP NMS	Jan 06 17:47:40	User Login.	User:admin	
SNMP Rec'rs	Jan 06 17:45:43	Auto Logout.	User:admin	
Users	Jan 06 17:26:06	User Login.	User:admin	
Email Alerts	Jan 06 17:24:54	User Logout.	User:admin	
Time Settings	Jan 06 17:24:45	User Login.	User:admin	
Syslog Servers	Jan 06 17:10:37	User Logout.	User:admin	
Events	Jan 06 17:07:53	User Login.	User:admin	
Preferences	Jan 06 17:06:26	Auto Logout.	User:admin	
Restart	Jan 06 16:59:38	User Login.	User:admin	
	Jan 01 00:00:12	Web Preferences Change.	User:System	Skin Id: 255
	Jan 16 01:17:33	Application Image Updated.	User:System	
	Jan 16 00:33:52	User Login.	User:admin	
	Jan 15 22:37:31	Auto Logout.	User:admin	
	Jan 15 20:32:21	User Login.	User:admin	
	Jan 15 20:31:48	Auto Logout.	User:admin	
	Jan 15 20:26:30	User Login.	User:admin	
	Jan 15 20:06:03	Auto Logout.	User:admin	
	Jan 15 20:00:49	User Login.	User:admin	
	Jan 15 19:42:24	Auto Logout.	User:admin	
	Jan 15 19:37:18	User Login.	User:admin	


To specify a range of events to view, select the desired year and month from the drop-down menus, then click **Show**.

Date/Time, Type, User, and Event Data for each event are displayed.

Events can be ordered **Latest First** or **Earliest First** by clicking the corresponding radio button.

## Preferences


The **Preferences** page allows you to edit system preferences.



Preferences	
Default Page	From the dropdown menu, select the first page you want to open when a user logs in. The preset default page is the Overview page.
Time stamp Traps	Choose from the dropdown menu where the timestamp will be found on traps. There are three options: <ul style="list-style-type: none"> <li>• Prefix – timestamp at the beginning</li> <li>• Append – timestamp at the end</li> <li>• None – no timestamp</li> </ul>
User Session Timeout	Enter a number of minutes, after which a session will be timed out if the user is inactive.
Temperature Scale	Select Celsius, Fahrenheit, or Kelvin from the dropdown menu.
Page Refresh Period	Enter a number of seconds, after which the page will automatically refresh. If 0 is entered, the page will not refresh automatically.

## Restart

Clicking the **Restart** option brings up the following screen:



To restart the unit or restore to factory defaults, click the corresponding button.

**Note:** Resetting to factory defaults will restart the device.

# Input Sensors

When the **Input Sensors** module is selected, the following items appear along the left-hand side of the display.

Input Sensors Menu Options	
Status	View information from connected input sensors
Defaults	View or edit default settings for input sensors
Configure	Configure sensor inputs
Sensor Trap Text	View or edit trap text

Detailed information on each of these menu options can be found in the corresponding sections below.

## Status

The **Status** page displays information from connected input sensors.

Logged In: admin ( Administrator )  
System Name: iPDU-04:01:19  
Logout

Setup Input Sensors Power

Input Sensors / Status

Status  
Defaults  
Configure  
Sensor Trap Text

Information from connected input sensors is presented here.

Channel	Type	Detected	Status	Value	Limits			
					UC	UW	LW	LC
1: Input 01	Auto Detect	None	Fault	---	N/A	N/A	N/A	N/A
✓ 2: Input 02	Auto Detect	Temperature	Enabled	24.9 °C	35.0	30.0	15.0	10.0

The following **Status Indicators** are displayed next to input channels to allow quick determination of normal, warning, and critical alarm statuses.


Status Indicators	
	All thresholds within limits
	Upper Control Limit reached/exceeded
	Upper Warning Limit reached/exceeded
	Lower Warning Limit reached/exceeded
	Lower Control Limit reached/exceeded

This page may also display the strings "O/R" and "U/R" in place of the input sensor measurement. This indicates an over-range or under-range condition.


- **O/R** - Value is Over Range
- **U/R** - Value is Under Range

## Defaults


This page allows you to choose default settings for **Temperature Sensors**, **Humidity Sensors**, **Analog Voltage**, and **Open/Close Contacts**.




Clicking the arrow opens a drop-down for each Sensor type. For **Temperature Sensors**, the defaults will display similar to the following:



The **Humidity Sensors** screen displays default information as shown below.



The **Analog Voltage** screen displays default information as shown below.



Explanations of the editable fields in the drop-down menus for Temperature, Humidity and Analog Voltage can be found in the table below.

Defaults- Temperature, Humidity, and Analog Voltage	
Scaling Factor (Analog Voltage only)	<p>The scaling factor is a value multiplied against the measured Analog Voltage to produce the Input Sensor measurement.</p> <p><i>Example:</i> Given a measurement of 10 Volts on the input sensor and a Scaling Factor of 100, the web UI and SNMP interface will report a value of <math>10 \times 100 = 1000</math> Volts as the sensor measured value.</p> <p><b>Note:</b> The <b>[Upper Lower] [Control Warning] Limit</b> fields apply to the post-scaled value.</p>
Calibration Offset	<p>Alters the actual reading of a sensor by the amount specified.</p> <p><i>Example:</i> If a Calibration offset of 6 was used and a sensor's true reading was 36, the indicated reading used for display</p>

Defaults- Temperature, Humidity, and Analog Voltage	
	and alarm purposes would be 42. This works in an identical way for both temperature and humidity sensors.
Hysteresis Value	The hysteresis default value to be applied to sensors is. The value specified is an offset from a sensor's threshold values. <i>Example:</i> A hysteresis value of 5 would mean that in the case of an Upper Control Limits alarm, the alarm value would have to reduce to 5 below the threshold value before another alarm is issued.
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Lower Warning Limit	The value at which a Lower Warning alarm will be issued.
Lower Control Limit	The value at which a Lower Control alarm will be issued.

The **Open/Close Contacts** screen displays the following default information.

The screenshot displays the PANDUIT web interface. At the top right, it shows 'Logged In: admin ( Administrator )', 'System Name: iPDU-04:01:19', and a 'Logout' link. Below this are three tabs: 'Setup', 'Input Sensors', and 'Power'. The 'Input Sensors' tab is active, showing a sub-header 'Input Sensors / Defaults'. A left-hand navigation menu includes 'Status', 'Defaults', 'Configure', 'Sensor Trap', and 'Text'. The main content area under 'Defaults' contains a descriptive paragraph and four expandable sections: 'Temperature Sensors', 'Humidity Sensors', 'Analog Voltages', and 'Open/Close Contacts'. The 'Open/Close Contacts' section is expanded to show configuration options: 'Normal State' is a dropdown menu set to 'Normally Open'; 'Trigger Type' is a dropdown menu set to 'Level'; 'Traps' is a dropdown menu set to 'Disabled'; and 'Repeat Timer' is a text input field set to '0' with the unit 'Seconds'. At the bottom right of this section are two buttons: 'Apply To Contacts' and 'Save'.

Defaults- Open/Close Contacts	
Normal State	<p>Normal state specifies the condition in which a contact is considered to be 'Normal', 'Non-alarmed' state. Devices such as smoke alarms and air conditioning units often have normally open contacts. In order to receive alarm indications from these types of units, setting normally open would cause alarms to be issued when the monitored contact closes. Setting normally closed, in the case of a rack cabinet door, would cause an alarm condition when the door was opened.</p>
Trap Alarm Level	<p>Rather than using <b>[Upper Lower] [Control Warning] Limit</b> settings, the <b>Open/Close Contact</b> sensors provide a Trap Alarm Level drop down menu with the following options:</p> <ul style="list-style-type: none"> <li>• Disabled</li> <li>• Critical</li> <li>• Warning</li> <li>• Information</li> </ul> <p>When the Trigger Type state occurs, if the <b>Trap Alarm Level</b> is not Disabled, a trap with the given Trap Alarm Level string content is generated.</p>
Trigger Types	<p>Trigger type defaults for Open/Close sensors are specified here. The three available options for trigger types are:</p> <p><b>Level</b> Level triggering is the default mode. When an input physically transitions from a Normal to Non-Normal state an alarm will be triggered. However the alarm will only persist while the input remains in a Non-Normal state. When the input returns to a normal state the alarm will be cleared.</p> <p><b>Normal to Non-Normal (Positive Edge)</b> This type of triggering may be used in situations where a momentary type input (e.g. shock sensor, PIR etc.), is used. Since these types of inputs are momentary any alarm condition which occurs, no matter how short, will persist until manually cleared. Positive Edge triggering is used when</p>

Defaults- Open/Close Contacts	
	<p>an alarm is required to persist after an input changes from the Normal state to the Non-Normal state.</p> <p><b>Non-Normal to Normal (Negative Edge)</b>                      This type of triggering may be used in situations where a momentary type input (e.g. shock sensor, PIR etc.), is used. Since these types of inputs are momentary any alarm condition which occurs, no matter how short, will persist until manually cleared. Negative Edge triggering is used when an alarm is required to persist after an input changes from the Non-Normal state to the Normal state.</p>
Repeat Timer	Causes alarm traps to be reissued after a specified amount of time if the alarm condition is still present. Setting the timer to zero (0) disables repeat traps.

The drop-down menus can be closed by clicking on the corresponding arrows again.

## Configure

The **Configure** page, shown below, allows you to configure sensor inputs.

Logged In: admin ( Administrator )  
 System Name: IPDU-04:01:19  
 Logout

Setup Input Sensors Power

Input Sensors / Configure

Status

Defaults Configure sensor inputs here.

Channel	Name	Type	Detected
1: Cfg 1	Input 01	Auto Detect	None
2: Cfg 2	Input 02	Auto Detect	Temperature

Sensor Trap Text

Clicking one of the configuration buttons – **Cfg 1** or **Cfg 2** – displays the following screen:

Logged In: admin ( Administrator )  
System Name: iPDU-04:01:19  
Logout

Setup Input Sensors Power

Input Sensor / Configuration : Port 1

Status

Defaults

Configure

Sensor Trap Text

Name: Input01

Type: Auto Detect

Temperature Sensor

Humidity Sensor

Analog Voltage

Open/Close Contact

Back Save

Individual settings can be entered for each input channel. The drop-down menu options are identical to the Defaults page.

**Note:** The important difference between the menus presented here and the menus presented on the Defaults page is that these settings are applied to individual channels.

The drop-down menus can be opened and closed by clicking the corresponding arrows.

## Sensor Trap Text

This page allows you to view or edit the text that will be displayed when certain events occur.

Logged In: admin ( Administrator )  
System Name: iPDU-04:01:19  
Logout

Setup Input Sensors Power

Setup / SNMP (Trap Definitions)

Status

Defaults When a "Data Type" sensor encounters a "Trap Type" event, the "User Text" is provided in the trap message.

Configure

Data Type	Trap Type	User Text
Temperature	UCL	Temperature Critically High
Temperature	UWL	Temperature Warning High
Temperature	LWL	Temperature Warning Low
Temperature	LCL	Temperature Critically Low
Humidity	UCL	Humidity Critically High
Humidity	UWL	Humidity Warning High
Humidity	LWL	Humidity Warning Low
Humidity	LCL	Humidity Critically Low
Voltage	UCL	Analog Critically High
Voltage	UWL	Analog Warning High
Voltage	LWL	Analog Warning Low
Voltage	LCL	Analog Critically Low

Save

Enter text to be displayed for each type of trap.

# Power

When the Power module is selected, the following menu items appear along the left-hand side of the display.

- Status
- Status 3-Phase (if the unit is 3-Phase)
- Branch Monitoring (if the unit has breakers)
- Thresholds
- Configure
- Control
- Config Outlet Groups
- Outlet Group Control

## Status Single-Phase


The **Status** screen displays information from a connected Single-Phase Power Device.

The screenshot shows the Panduit web interface. At the top right, it says "Logged In: admin ( Administrator )", "System Name: control/switching!", and "Logout". Below this are three tabs: "Setup", "Input Sensors", and "Power". The "Power / Status" section is active. On the left sidebar, the "Status" menu item is selected. The main content area displays "Information from connected Power Devices is presented here." followed by a table.

Circuit	Name	Outlets	Volts	Amps	kVA	PF	kW	Hz	kWh
01-L1	A1	<a href="#">View</a>	✓ 116	⚠ 0.0	✓ 0.0	0.78	✓ 0.0	60.0	✓ 54.9
01-L2	A2		⚠ 115	✓ 0.0	✓ 0.0	0.99	✓ 0.0		✓ 7.6
01-L3	A3		⚠ 116	✓ 0.0	✓ 0.0	0.00	✓ 0.0		✓ 51.7
Aggregate				✓ 0.0	✓ 0.0		✓ 0.0		114.2

## Status 3-Phase

If the device is 3-Phase, you will see the **3-Phase Status** button as shown below. The **3-Phase Status** screen displays information from a connected 3-Phase Power Device.



Many of the following pages use abbreviations for various units. A reference table is provided below for convenience.

Units of Measurement		
Current	Amps	Amperes
Power	kVA	Kilovolt amperes
	PF	Power Factor
	kW	Kilowatts
Frequency	Hz	Hertz
Energy	kWh	Kilowatt hours
	kVArh	Kilovolt amperes reactive hours


## Branch Monitoring

If the power device has breakers, you will see the **Branch Monitoring** button as shown below. Clicking the **Branch Monitoring** button brings up the following screen, displaying information from branch monitoring.



## Thresholds

The **Thresholds** screen displays threshold information from a connected Power Device.



## Configure

The **Configure** page allows you to view and configure Power Circuits. Depending on the type of unit, not all menu items shown below may be available.

Power / Configure

Control Method: HTTP-SNMP

Cycle Up/Down Delay: 1 Seconds

Repeat Timer: 600 Seconds (On Comms Failure)

Cycle Password: [Redacted]

Reboot Delay: 10 Seconds

Abort Cycle Delay: 20 Seconds

Circuit	Name	Outlets	Type
01-L1	A1	24	Per Outlet Monitor and Control
01-L2	A2		
01-L3	A3		
Agg.	Aggregate	N/A	Calculated

Configuration for the Aggregate of all circuits


Monitor Trap Text      Outlets Trap Text

Save

Power Circuit configuration parameters include the following:


Power Circuit Configuration Parameters	
Control Method	Specifies which control methods are available to control the outlets. Available selections are HTTP+SNMP, HTTP Only, SNMP Only, and RS232 Only.
Cycle Up/Down Delay	Specifies the interval in seconds between switching on and switching off outlets when an entire PDU strip is cycled (all outlets commanded on or off).
Repeat Timer	Specifies the interval in seconds between when an initial PDU comms failure trap is produced and a repeat trap is issued.
Cycle Password	Specifies the password required to set a power cycle of outlets on a controllable strip. This password is used when switching outlets using SNMP, not when switching via the web interface.
Reboot Delay	Specifies how long (in seconds) an outlet remains off after a reboot before switching back on.
Abort Cycle Delay	Specifies how many seconds must elapse before a commanded abort cycle begins. This delay gives the user time to reverse the decision to cycle a PDU before any outlet states are changed.

Clicking the configuration button – **Cfg** – for a specific circuit brings up a screen similar to the following.



At the top of the screen the Circuit Name, Cycle Password and Power On Mode are displayed. Clicking on the arrows next to each option reveals the parameters for that option.


## RMS Volts



Explanations of the editable fields within the drop-down menus can be found in the table below.

RMS Volts	
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Lower Warning Limit	The value at which a Lower Warning alarm will be issued.
Lower Control Limit	The value at which a Lower Control alarm will be issued.
Trap Enabled	When the box is checked, enables the unit to send traps relating to the corresponding limit
Repeat Timer	This entry (in seconds) determines how often repeat traps will be generated if the error condition persists.

## RMS Current



Explanations of the editable fields within the drop-down menus can be found in the table below.

RMS Current	
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Lower Warning Limit	The value at which a Lower Warning alarm will be issued.
Lower Control Limit	The value at which a Lower Control alarm will be issued.
Trap Enabled	When the box is checked, enables the unit to send traps relating to the corresponding limit
Repeat Timer	This entry (in seconds) determines how often repeat traps will be generated if the error condition persists.

## Total Energy

Logged In: admin ( Administrator )  
System Name: control/switching!  
Logout

Setup Input Sensors Power

Power / Configure : Device 1 L1 [A1]

**Status**

Status 3-Phase Circuit Name: A1

Branch Monitoring Cycle Password:

Power On Mode: All On

**Configure**

RMS Volts

RMS Current

Total Energy (kWh)

Limits & Traps:

	Value:	Trap Enabled:	Repeat Timer:
Upper Control Limit:	50000.0 kWh	<input checked="" type="checkbox"/> Enabled	0 Seconds
Upper Warning Limit:	48000.0 kWh	<input checked="" type="checkbox"/> Enabled	0 Seconds

Apparent Power (kVA)

True Power (kW)

Power Factor


Power Strip Outlets

Back Save

Explanations of the editable fields within the drop-down menus can be found in the table below.

Total Energy	
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Trap Enabled	When the box is checked, enables the unit to send traps relating to the corresponding limit
Repeat Timer	This entry (in seconds) determines how often repeat traps will be generated if the error condition persists.

## Apparent Power



Explanations of the editable fields within the drop-down menus can be found in the table below.

Apparent Power	
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Trap Enabled	When the box is checked, enables the unit to send traps relating to the corresponding limit
Repeat Timer	This entry (in seconds) determines how often repeat traps will be generated if the error condition persists.

## True Power

Logged In: admin ( Administrator )  
System Name: control/switching!  
Logout

Setup Input Sensors Power

Power / Configure : Device 1 L1 [A1]

Status

Status 3-Phase Circuit Name: A1

Branch Monitoring Cycle Password:

Power On Mode: All On

Thresholds

Configure

RMS Volts

Control

RMS Current

Config Outlet Groups

Total Energy (kWh)

Outlet Group Control

Apparent Power (kVA)

True Power (kW)

Limits & Traps:

	Value:	Trap Enabled:	Repeat Timer:
Upper Control Limit:	12.0 kW	<input checked="" type="checkbox"/> Enabled	0 Seconds
Upper Warning Limit:	11.0 kW	<input checked="" type="checkbox"/> Enabled	0 Seconds

Power Factor


Power Strip Outlets

Back Save

Explanations of the editable fields within the drop-down menus can be found in the table below.

True Power	
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Trap Enabled	When the box is checked, enables the unit to send traps relating to the corresponding limit
Repeat Timer	This entry (in seconds) determines how often repeat traps will be generated if the error condition persists.

## Power Factor



Explanations of the editable fields within the drop-down menus can be found in the table below.

Power Factor	
Upper Control Limit	The value at which an Upper Control alarm will be issued.
Upper Warning Limit	The value at which an Upper Warning alarm will be issued.
Trap Enabled	When the box is checked, enables the unit to send traps relating to the corresponding limit
Repeat Timer	This entry (in seconds) determines how often repeat traps will be generated if the error condition persists.

## Power Strip Outlets

The screenshot shows the PANDUIT web interface. At the top right, it says "Logged In: admin ( Administrator )" and "System Name: control/switching!". Below this are buttons for "Setup", "Input Sensors", and "Power". The left sidebar has a menu with items like "Status", "Status 3-Phase", "Branch Monitoring", "Thresholds", "Configure", "Control", "Config Outlet Groups", and "Outlet Group Control". The main area shows a configuration table for "Power Strip Outlets".

Outlet	Name	Password	Cycle Delay
1	A01		1
2	A02		2
3	A03		3
4	A04		4
5	A05		5
6	A06		6
7	A07		7
8	A08		8
9	A09		9
10	A10		10
11	A11		11

Buttons for "Save", "Back", and "Save" are visible in the interface.

The Power Strip Outlets section allows you to update the **Name**, **Password** and **Cycle Delay** for any individual Outlet. Click the **Save** button to implement the changes.

## Cfg Aggregate

Click the configuration button – **Cfg** – for the Aggregate (Agg) to configure all the circuits.

Power / Configure

Control Method: HTTP + SNMP

Cycle Up/Down Delay: 1 Seconds

Repeat Timer: 600 Seconds (On Comms Failure)

Cycle Password:

Reboot Delay: 10 Seconds

Abort Cycle Delay: 20 Seconds

Circuit	Name	Outlets	Type
01-L1	A1	24	Per Outlet Monitor and Control
01-L2	A2		
01-L3	A3		
Agg.	Aggregate	N/A	Calculated

Monitor Trap Text

Outlets Trap Text

Save

When Cfg is selected, a screen appears showing the settings for **RMS Current**, **Apparent Power (kVA)** and **True Power (kW)**. The definitions for the displayed fields are the same as found in the corresponding [RMS Current](#), [Apparent Power](#), and [True Power](#) sections.

RMS Current

Value:	Trap Enabled:	Repeat Timer:
Upper Control Limit: 30.4 Amps	<input type="checkbox"/> Enabled	0 Seconds
Upper Warning Limit: 28.8 Amps	<input type="checkbox"/> Enabled	0 Seconds
Lower Warning Limit: 0.0 Amps	<input type="checkbox"/> Enabled	0 Seconds
Lower Control Limit: 0.0 Amps	<input type="checkbox"/> Enabled	0 Seconds

Apparent Power (kVA)

Value:	Trap Enabled:	Repeat Timer:
Upper Control Limit: 9.5 KVA	<input type="checkbox"/> Enabled	0 Seconds
Upper Warning Limit: 8.5 KVA	<input type="checkbox"/> Enabled	0 Seconds

True Power (kW)

Value:	Trap Enabled:	Repeat Timer:
Upper Control Limit: 12.0 kW	<input type="checkbox"/> Enabled	0 Seconds
Upper Warning Limit: 11.0 kW	<input type="checkbox"/> Enabled	0 Seconds

## Monitor Trap Text

Clicking the **Monitor Trap Text** button brings up screen to customize the text displayed for each trap type.

Logged In: admin ( Administrator )  
System Name: sysName  
Logout

Setup   Input Sensors   Power

Setup / SNMP (Trap Definitions)

Status

Status 3-Phase When a "Data Type" sensor encounters a "Trap Type" event, the "User Text" is provided in the trap message.


Branch Monitoring	Data Type	Trap Type	User Text
Thresholds	PDU Volts	UCL	Voltage Critically High
Configure	PDU Volts	UWL	Voltage Warning High
Control	PDU Volts	LWL	Voltage Warning Low
Config Outlet Groups	PDU Volts	LCL	Voltage Critically Low
Outlet Group Control	PDU Amps	UCL	Amps Critically High
	PDU Amps	UWL	Amps Warning High
	PDU Amps	LWL	Amps Warning Low
	PDU Amps	LCL	Amps Critically Low
	PDU kWhr	UCL	kWhr Critically High
	PDU kWhr	UWL	kWhr Warning High
	PDU kVA	UCL	kVA Critically High
	PDU kVA	UWL	kVA Warning High
	PDU Pwr Fact	UTL	Power Factor High
	PDU Pwr Fact	LTL	Power Factor Low

Back   Save

Enter the desired text in the text box provided, and click the **Save** button to implement your customization.

## Outlet Trap Text


Clicking the **Outlet Trap Text** button brings up screen to customize the text displayed for each trap type.




Enter the desired text in the text box provided, and click the **Save** button to implement your customization.

## Control


The **Control** page allows you to view and configure individual or all outlets.




Click the red information symbol to view the names of the individual outlets.



Click the yellow lightning bolt to turn on or turn off the entire power strip.




Click any of the individual outlets to change the state or reboot the outlet.




## Config Outlet Groups

The **Config Outlet Groups** screen allows you to configure individual outlets into logical groups.



To begin creating an Outlet Group, click **Config** next to the desired Group Name. The Configuration screen appears, as shown below. Enter a **Group Name** and **Password** and click the **Group Enabled** box to enable the group.

Select the members of the group by selecting individual outlets from the drop down outlet list.




Click the **Save** button to create the Outlet Group.

**Note:** An outlet cannot be a member of more than one Outlet Group. An Outlet Group's contents must be unique.

## Outlet Group Control

The Outlet Group Control screen is similar to the Control screen, except that logical groups are displayed rather than individual outlets. The screen below shows the display for the test Outlet Group created in the previous section.



All of the functionality of the Control screen is also available here. See [Control](#) for additional details.